


# KLM100T

## T-stuk voor KLM100



Radius: 600 mm

	200	300	400	500	600
A	1962	2062	2162	2262	2362

### Te bevestigen met:



Zelfborgende  
kraagbout (DIN  
603)  
RBK

Zelfborgende  
flensmoer (DIN  
6923)  
RM

Artikel	Afwerking	↑ mm	↔ mm	→  ← mm	↔ mm	kg/stk	📦	Eenh.
<b>KLM100T150</b>	SZ	100	158			9,460	1	STK
<b>KLM100T200</b>	SZ	100	208			11,550	1	STK
<b>KLM100T300</b>	SZ	100	308			12,742	1	STK
<b>KLM100T400</b>	SZ	100	408			13,906	1	STK
<b>KLM100T450</b>	SZ	100	458			14,342	1	STK
<b>KLM100T500</b>	SZ	100	508			16,719	1	STK
<b>KLM100T600</b>	SZ	100	608			17,712	1	STK
<b>KLM100T750</b>	SZ	100	758			19,508	1	STK
<b>KLM100T800</b>	SZ	100	808			20,106	1	STK
<b>KLM100T900</b>	SZ	100	908			21,962	1	STK
<b>KLM100T1000</b>	SZ	100	1008			23,236	1	STK
<b>ZMKLM100T150</b>	DF	100	158			9,460	1	STK
<b>ZMKLM100T200</b>	DF	100	208			11,550	1	STK
<b>ZMKLM100T300</b>	DF	100	308			12,742	1	STK
<b>ZMKLM100T400</b>	DF	100	408			13,906	1	STK
<b>ZMKLM100T450</b>	DF	100	458			14,342	1	STK
<b>ZMKLM100T500</b>	DF	100	508			16,719	1	STK
<b>ZMKLM100T600</b>	DF	100	608			17,712	1	STK
<b>ZMKLM100T750</b>	DF	100	758			19,508	1	STK
<b>ZMKLM100T800</b>	DF	100	808			20,106	1	STK
<b>ZMKLM100T900</b>	DF	100	908			21,962	1	STK
<b>ZMKLM100T1000</b>	DF	100	1008			23,236	1	STK

Minimum aantal bouten en moeren: 12 stuks.

### Legende afwerking

- SZ = Sendzimir
- DF = Defender

