

# KLWT

## T-stuk voor KLW



### Te bevestigen met:



Zelfborgende  
flensmoer (DIN  
6923)  
RM

Zelfborgende  
kraagbout (DIN  
603)  
RBK

Radius: 600 mm

	200	300	400	500	600
A	1962	2062	2162	2262	2362

Artikel	Afwerking	↕ mm	↔ mm	→  ← mm	↔ mm	kg/stk	📦	Eenh.
<b>KLWT200</b>	SZ	200	208			17,488	1	STK
<b>KLWT300</b>	SZ	200	308			18,798	1	STK
<b>KLWT400</b>	SZ	200	408			19,982	1	STK
<b>KLWT500</b>	SZ	200	508			21,167	1	STK
<b>KLWT600</b>	SZ	200	608			24,129	1	STK
<b>ZMKLWT200</b>	DF	200	208			17,488	1	STK
<b>ZMKLWT300</b>	DF	200	308			18,798	1	STK
<b>ZMKLWT400</b>	DF	200	408			19,982	1	STK
<b>ZMKLWT500</b>	DF	200	508			21,167	1	STK
<b>ZMKLWT600</b>	DF	200	608			24,129	1	STK

Minimum aantal bouten en moeren: 12 stuks.

### Legende afwerking

- SZ = Sendzimir
- DF = Defender