


DOVGV.2

Cover for flush floor trunking

For hinged cover KDVKK2 and KDVIRK2.

| Reference | ↕ mm | ↔ mm | → ← mm | ↔ mm | kg/stk | 📦 | Unit |
|---------------------|---------|---------|------------|---------|--------|---|------|
| DOVGV250.3.2 | | 250 | 3 | 800 | 3,313 | 1 | STK |



Replace the clamps of the hinged cover by the enclosed clamps of the DOVG. Replace the cover where you want to mount the flush mounting unit with a cover for the relevant flush mounting unit. Place the flush mounting unit in the opening provided. Fasten the flush mounting unit by tightening the clamps.